

XL785 VOICE /
XL785 VOICE DUO /
XL785 VOICE TRIO



The diagram shows the front and back of the mobile phone. The front view includes callouts for the earpiece (11), display (1), M1, M2, and M3 function keys (6), the 'END CALL' key (2), the 'CALL' key (3), the 'CALL WAITING' key (4), the 'CALLER ID' key (5), the numeric keypad (9), and the '*' and '#' keys (8). The back view shows the camera lens (12).












7. **# key**
Press to insert #
In idle mode: Press and hold to access the call list.
In predialling mode / during a call:
Press and hold to insert pause.
8. *** key**
Press to insert *
In idle mode: press and hold to access the redial list.
9. **ALPHANUMERIC KEYPAD**
Press to insert a digit / character / * / #
0 key in predialing / number editing mode:
Press and hold to insert a flash
1, 2, 3 key in idle/off hook mode, press and hold to
dial the stored direct memory number.
0 key during a call: Press and hold to start conference
call(in intercom mode).
10. 
In idle / predialing mode : Press to make a call.
In Redial list / Call List / Phonebook entry:
Press to make a call to the selected entry in the list.
During ringing: Press to answer a call.
During a call: Press to switch to speaker mode.
11. **HANDSET LED** 
During charging: On steadily.
In ringing mode / Paging mode: Flashing quickly.
When new voice mail: Flash slowly
When new voice mail or new voice message (TAM):
Flash slowly.
12. **AUDIO BOOST** 
During a call: Press to audio boost on/off
(inactive in speakerphone mode).


Diagram showing the front and back views of the device with numbered callouts 1 through 12. The front view shows a screen, a speaker grille, and a control panel with buttons labeled M1, M2, and M3. The back view shows a camera lens, a microphone, and a battery compartment.

- | | |
|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A1/A2 | Steadily ON: Playing the current outgoing message (OGM) where A1 is the Answer & Record OGM and A2 is the Answer Only OGM |
| XX/An | Flash XX alternatively with An: XX new incoming message is now recording. An denotes that the incoming message recording is in progress |
| rA | Flash: Remote access is in progress |
| LX | Steadily ON: Indicate the current volume level where X is from 1 to 8 (non-cyclic) |
| CA | Steadily ON: when the base unit is in conversation mode |
| 4. | TAM ON/OFF 
Press to turn on the answering machine
Press again to turn off the answering machine |
| 5. | PLAY/STOP 
Press to play the message
Press again to stop the message playback |
| 6. | SKIP FORWARD 
Press to skip the current message and play the next message |
| 7. | DELETE 
Press once to delete the message during playback
Press and hold to delete all the messages
Note: New voice messages will not be deleted |
| 8. | SKIP BACKWARD 
Press to repeat playing the current message from the beginning
Press twice to skip backward to the previous message |
| 9. | VOLUME DOWN 
Decrease (+) speaker volume during message playback |
| 10. | IN USE LED-BLUE 
Steadily on while the handset is in use, or base is in conversation mode
Flashes when receiving an incoming call, or handset is off cradle during registration |
| 11. | M1, M2, M3
In idle mode: Press M1, or M2, or M3 key to dial out the stored number |
| 12. | TALK KEY 
During ringing: Press to answer a call |


 CLAUDIA
 1234567890

- Indicates when the battery is fully charged.
Whole icon flashes when the battery performs initial charging.
Internal block icon flashes when the battery is in final charging stage.

- ### **3. INSTALLING YOUR PHONE**
- #### **3.1. Connecting the Base Station**
1. Plug one end of the telephone line cord into the telephone jack on base bottom.
 2. Plug the small end of power adapter into a power jack on base bottom.
 3. Plug the large end of power adapter into a wall power outlet.
 4. Plug the other end of the telephone line cord in to the telephone jack or micro-filter.
 5. Always use the cables provided in the box.



3.2. Installing and Charging the Batteries

1. Slide down to open the battery compartment cover.
2. Place the 2 batteries as indicated.
Pay extra attention to direction of Respect polarity.
3. Slide the battery compartment cover back.
4. Put the handset on the base and charge for 8 hours before using the handset for the first time.
The handset will give a beep when it is properly placed on the base or charger.

A detailed line drawing showing the connection of the battery pack to the motor unit. The battery pack consists of two cylindrical cells connected in series. Wires from the battery pack are connected to the motor unit's terminal block. The motor unit is shown in a side profile, with the battery pack connected to its rear. The diagram illustrates the correct orientation and connection of the battery pack to the motor unit.

Country

England *
Italy
France

Resetting
Please Wait

Pls Set Time
Date & Time

DD-MM-YY *
MM-DD-YY

01-01-2021

12 HR
24 HR

HH:MM
00:00





OK MENU




OK MENU

OK MENU




e.g. 00:00

Change language (Handset)

- Press  on the handset in idle mode.
- Press  or  to select **"HS Settings"**(1), then press .
(1)

EN	FR	DE	IT
HS Settings	Régl. Comb.	Mt-Einstel.	Imposta Port
NL	ES	PT	
Handset Inst	Conf Telef.	Config. Term	
- Press  or  to the menu **"Language"**(2), then press .
(2)



EN	FR	DE	IT
HS Settings	Régl. Comb.	Mt-Einstel.	Imposta Port
NL	ES	PT	
Handset Inst	Conf Telef.	Config. Term	

3. Press  or  to the menu **"Language"**(2), then press .

(2)

EN	FR	DE	IT
Language	Langue	Sprache	Lingua
NL	ES	PT	
Taal	Idioma	Idioma	
















- Press or to the desired language, then press . OK MENU
- 4. USING YOUR PHONE**
- 4.1. Make a Call**
- 4.1.1. Preparatory Dialing**
Enter the phone number and press to dial the number.
Press to clear the entry.
- 4.1.2. Direct Dialing**
Press to take the line and enter the phone number.
- 4.1.3. Dial from Direct Memory Keys**
In idle or off hook mode,
Press **M1**, **M2** or **M3** to dial the stored number.
Press and hold / / to dial the direct memory number. You have to store number to the related key first. See section 8.3 for reference.
- 4.1.4. Call from the Redial List**
Press and hold to access the redial list and press / to select the desired redial number.
Press to dial out to the selected redial number.
- 4.1.5. Adjust Earpiece and Handsfree Volume**
There are 5 levels (VOLUME 1 to VOLUME 5) to choose from for each of earpiece and handsfree volume.
- During a call:
- Press / to select volume 1-5. The current setting is shown. When you end the call, the setting will remain at the last selected level.
- The current volume is displayed on the screen.
- When you end the call, the new volume setting sound remains valid for subsequent calls.

For the sound level of the handset, if this is not loud enough, press  , the audio boost will be activated (+10dB). To turn off audio boost, press again the key  .







5. PRIVATE PHONEBOOK

Your phone can store up to 100 private phonebook entries with names and numbers. Each phonebook entry can have a maximum of 24 digits for the phone number and 12 characters for the name. You can also select different ringtones for your phonebook entries. Phonebook entries are stored alphabetically by name.

5.1. Add a New Phonebook Entry

- In idle:
- Press  to access the phonebook. OR Press  and  /  to select **Phonebook** main menu item and then press  to access the phonebook.
 - Press  to select **Add New**.
 - Press  to enter the name.
 - Press  to enter the number.
 - Press  and  /  to select the desired ringtone for your phonebook entry.
 - Press  to confirm the melody,
 - Press  or  to select VIP X or VIP √.
 - Press  to confirm to save it as normal contact list (VIP X) or save it in VIP list (VIP √). Note: ! appears in the end of name of VIP entry.


5.2. Call from the Phonebook







- In idle:
- Press  to access the phonebook. OR Press  and  /  to select **Phonebook** main menu item and then press  to access the phonebook.
 - Press  to dial out to the selected phonebook entry. Phonebook is stored in base unit which is shared with duo, trio handsets.

6. CALLER DISPLAY (NETWORK DEPENDENT)*
This feature* is available if you have subscribed the Caller Line Identification service with your telephone service provider. Your phone can store up to 50 received calls with date/time information in the Call List. The number will be shown on the LCD when the phone is ringing.






If the caller number is disabled to send caller information, **“Withheld”** will display.
If the caller number is not provided, **“Out of Area”** will display.
In standby, if three unanswered calls are received, **“3 New Calls”** will be displayed.

6.1. View the Call List




All received calls are saved in Call List with the latest call putting at the top of the list. When the call list is full, the oldest call will be replaced by a new call. The unanswered call which has not been read is marked with  .

- Press and hold **#** key. OR Press  and  /  to select **Call List**, press  .
- Press  /  to select the desired entry.

6.2. Call from the Call List














- In idle:
- Press and hold **#** key. OR Press  and  /  to select **Call List**, press  .
 - Press  to dial out to the selected phonebook entry.

7. REDIAL THE LAST NUMBER















- You can redial up to 10 of the last numbers called.
- In idle mode, press and hold ***** key to access the redial list.
 - Press  or  to browse the redial list.
 - Press  to dial the selected redial number.

8. PHONE SETTING





8.1. Set the Ringer Melody for Internal/ External Calls

- Press  and  /  to select **HS Settings**.
- Press  and  /  to select **Ring Setup**.
- Press  and  /  to select **INT Ring** or **Ext Ring**.
- Press  and  /  to select the desired ringer melody from the melody list.
Note: The respective ringer melody will be played while browsing the melody list.
- Press  o confirm.








8.2. Set the Ringer Volume

- Press  and  /  to select **HS Settings**.
- Press  and  /  to select **Ring Setup**.
- Press  and  /  to select **Ring Volume**.
- Press  and  /  to select the desired ringer volume (a total of 6 ringer volume levels including **Off**).
Note: The respective ringer volume will be played during your selection.
If **Off** is selected,  icon will display.
- Press  to confirm.



8.3. Set the Speed Dial

- Press  and  or  to select **Direct Mem**.
- Press  , and then press the memory key M1/M2/M3/<KEY 1>/< KEY 2>/< KEY 3>.

For M1/M2/M3:

- Press  to input name
- Press  to enter number
- Press  to browse the melody list, and then press  to confirm the melody,
- Press  or  to select VIP X or VIP √.
- Press  to confirm to save it as normal contact list (VIP X) or save it in VIP list (VIP √).

For <KEY 1>/< KEY 2>/< KEY 3>:

- Press  to input number, and then press  to confirm.




9. Answering Machine

Your phone includes a telephone answering machine that records unanswered calls when it is on. The LED message counter (two digits seven segment display) on the base will show the number of the messages when the answering machine is on. The answering machine can store up to 59 messages within the maximum recording time of approximately 30 minutes. As well as recording incoming messages, you can record memos for other users of your phone. If the answering machine memory is full, the Handset will display **Memory Full** and the handset name alternatively in standby, or display **Memory Full** and the date/time information in standby.









9.1. Turn On/Off the Answering Machine



You can turn on or off the answering machine through the base or handset. When the answering machine is set to **On**, calls will be answered after the set answer delay and the caller can then leave you a message. When the answering machine is set to **Off**, calls will be answered after 12 rings and the answer only message will be played to your callers. They will not be able to leave you a message.

Through the Base:


- Press  on the base station.
 - If answering machine is set to **On**,  displays on the handset LCD and the 7-seg LED on the base station will display the number of incoming messages.
 - If answering machine is set to **Off**,  will disappear from the handset LCD and the 7-seg LED on the base station will display - -.

Through the Handset:












- Press  and  /  to select **Ans. Machine**.
- Press  and  /  to select **Tam On/Off**.
- Press  and  / to select **On** or **Off**.
- Press to confirm.


- If answering machine is set to **On**,  displays on the handset LCD and the 7-seg LED on the base station will display the number of incoming messages.
- If answering machine is set to **Off**,  will disappear from the handset LCD and the 7-seg LED on the base station will display - -.



9.2. Listen to the Messages in the Answering Machine

When new messages are recorded on the answering machine,  flashes on the handset display and the message counter on base flashes with the number of new messages in the answering machine until all the new messages are played. Old messages will be played after all new messages are played completely.


Listen new messages through the Base:

- Press  on the base station.
 - The new messages are played from the loudspeaker on the base station in the sequence they are recorded.
 - Press  or  on the base station to increase or decrease the volume during message playback respectively.
Note: If there are no new messages, “00” will display steadily in the message counter on the base. Press  will have no effect and an alert tone is emitted.
- Listen new messages through the Handset:**
- Press  and  /  to select **Ans. Machine**.
 - Press  and  /  to select **Msg Playback**.
 - Press  to start message playback and the screen displays the date and time information of the message received.

For XL785 Voice, listen messages through the handset speaker by default or earpiece by pressing  to toggle between handset speakerphone and earpiece for listening the messages.

- During message playback, press  or  to increase or decrease the message playback volume respectively.

Note: After new message is played, the new message will be saved as an old message automatically unless it is deleted.







- Press  to select **Stop, Forward, Previous, Delete** to perform the following functions during message playback.

Stop: Stop the current message playback and return to the **Ans. Machine** menu.

Forward: Skip to play the next message. The date and time information of the next message ill display if there is next message.


Previous: Skip to repeat playing the current message from the beginning. The date and time information of the current message will display.

Delete: Delete the current message and the next message will be played.









- Note: Alternatively, you can use the following shortcut keys to control different operation during message playback.
- Press  to stop message playback.
 - Press  to skip to repeat playing the current message from the beginning. Press  to twice to skip backward to the previous message.
 - Press  to skip to play next message.
 - Press  to delete the current message playback.
 - Press  to confirm.

9.3. Delete All Messages in the Answering Machine

Delete all messages through the Base:

- In idle:
- Press and hold  on the base station.
 - All the old messages will be deleted.
Note: New messages will not be deleted. If there are no more messages in the answering machine, “00” will display on the base station.









Delete all messages through the Handset:

- Press  and  /  to select **Ans. Machine**.
- Press  and  /  to select **Delete All**.
- Press  to confirm.
- Press  to delete all old messages.


Note: If there are no more messages in the answering machine, **Empty** will display and return back to **Ans. Machine** menu.

9.4. Record Memo

You can record your memo message for another user. When you record a memo, the message counter will increase by one and the message can be played back in the same way as answering machine messages. Memo recording can still function even when the answering machine is turned off.

- Press  and  /  to select **Ans. Machine**.
- Press  and  /  to select **Memo**.
- Press  to start memo recording and **Recording** is displayed.
- Press  to stop memo recording and save the memo.

OR














- Press  to stop memo recording without saving and return back to **Ans. Machine** menu.

9.5. Answering Machine Settings

You can use the **Tam Settings** menu through the handset to change the settings of your answering machine.














9.5.1. Set the Answer Mode

By default, the answer machine is set in **Ans & Rec** mode which allows callers to leave a message. This mode can be changed to **Answer Only** which does not allow callers to leave a message. In that case, your callers will be prompted to call back later.

- Press  and  /  to select **Ans. Machine**.
- Press  and  /  to select **Tam Settings**.
- Press  and  /  to select **Answer Mode**.
- Press  and  /  to select **Ans & Rec** or **Answer Only**.
- Press  to confirm.













9.5.2. Set the Outgoing Message Language







The answering machine announces the outgoing message when it answers a call. There is a pre-set OGM for each of **Ans & Rec** mode or **Answer Only** mode. You are able to select your desired OGM language to playback.

- Press  and  /  to select **Ans. Machine**.
- Press  and  /  to select **Tam Settings**.
- Press  and  /  to select **Tam Language**.
- Press  and  /  your desired OGM language.
- Press  to confirm.

9.5.3. Record Your Own Outgoing Message (OGM)

You can record your own OGM for **Ans & Rec** mode or **Answer Only** mode. When you record your own OGM, it will be used when the answering machine answers the call. If your personalized OGM is deleted, the pre-set OGM will be restored automatically.


















- Press  and  /  to select **Ans. Machine**.
- Press  and  /  to select **Tam Settings**.
- Press  and  /  to select **OGM Settings**.
- Press  and  /  to select **Ans & Rec** or **Answer Only**.

- Press  and  /  to select **Record Mess**.
- Press  to start recording your personalized OGM and **“Recording”** is displayed on the screen.
- Press  to stop and save your personalized OGM. Your newly saved OGM will playback automatically. Alternatively, press  to return to previous screen without saving the personalized OGM.

9.5.4. Playback and Delete the Outgoing Message (OGM)


You can playback your own personalized OGM or the pre-set OGM for **Ans & Rec** mode or **Answer Only** mode and choose to delete your personalized OGM during playback and record a new one whenever you want. Please note that pre-set OGM cannot be deleted.



9.5.4.1. Playback the OGM

- Press  and  /  to select **Ans. Machine**.
- Press  and  /  to select **Tam Settings**.
- Press  and  /  to select **OGM Settings**.
- Press  and  /  to select **Ans & Rec** or **Answer Only**.
- Press  and  /  to select **Playback**.
- Press  to playback your personalized OGM (if you have recorded a personalized OGM before) and **“Playing OGM”** is displayed on the screen.
- Press  to stop the OGM playback and return to the previous menu.

Note: If a personalized OGM is not recorded before, the pre-set OGM will be played.

















9.5.4.2. Delete the personalized OGM

- Repeat Steps 1 to 6 in Section 9.5.4.1
- Press  to delete your personalized OGM and return to previous menu and the pre-set OGM is restored automatically.

Note: If pre-set OGM is playing, you are not allowed to delete the pre-set OGM and thus  will not display. Only  will display.

9.5.5. Set the Answer Delay

You can set the number of rings before the answering machine answers and starts playing your OGM. You can set the answering machine to answer after two to ten rings.

- Press  and  /  to select **Ans. Machine**.
- Press  and  /  to select **Tam Settings**.
- Press  and  /  to select **Answer Delay** (Available options: **2 Rings, 4 Rings, 6 Rings, 8 Rings** or **10 Rings**).
- Press  and  /  to select **Ans & Rec** or **Answer Only**.
- Press  and  /  to select your desired answer delay.
- Press  to confirm.

10. REGISTRATION

Your handset and base station is pre-registered. Up to 4 handsets can be registered to a single base station